# FABTEX®

ROLLER SHADES
Outside Mount Track

An Outside Mount roller shade is mounted on the wall over a window or at the ceiling. It's usually larger than the actual window opening so the window can be completely covered when the shade is drawn all the way down. Another option would be to use side and sill channels to achieve blackout conditions.

Roller shade with fascia

Continuous beaded chain operation

Side channel

Safety hold down device

Sill channel

WINDOW SECTIONAL VIEW

Brackets
Brackets are installed on the wall or the ceiling, on both ends. Screws are not provided.

Clutch, Tube & Pin End
The clutch, tube & pin end are shipped pre-assembled with the fabric and is ready for installation.

Adapter Sleeve

Bracket

Pin End

Aluminum Tube

Clutch End

## Chain & Hold Down Device

Beaded chain wraps around the clutch. Ball stops are installed on site to set the upper and lower limits.

Safety hold down device is mounted on the wall with provided mounting screws.

Fascia/Headbox

The fascia or headbox conceals the mechanism and comes in 4" or 5" options.

FASCIA - Single Shade

HEADBOX - Single Shade

FASCIA - Dual Shade

HEADBOX - Dual Shade

COLOR OPTIONS:

4" Single Shade	5" Single Shade	4" & 5" Dual Shade	Side/Sill Channel
• White	• White	• White	• White
• Clear Anodized	• Clear Anodized	• Clear Anodized	• Clear Anodized
• Bronze	• Bronze		• Bronze
• Black	• Black		
• Vanilla			

End Plates

The end plates provide a cleaner finish on the sides.